




AIR VALVE PLUMBING

Power on 2 when using Top Mount,
HEAD END of cylinder.
Power on 2 when using Side Mount,
PISTON END of cylinder.



SINGLE SWITCH OPERATION



DOUBLE SWITCH OPERATION

